

BULLETTM *SPEED BAR*
never BEHIND!

STANDARD [v2.0]
MODEL




bullet-speedbar.com

- > Correct operation is guaranteed by connecting the speedbar elastics to the footplate. In absence of factory loops at indicated height, We suggest using the provided clips by mounting them as shown below.

Basic tips

- > Speedbar layout and steps distance can be adjusted according to your preference. Try default before to change it.

- > For best comfort, first steps must be pushed with heel of foot.



- > Keep your speedbar operational and update. Find spare parts on our online shop.

- > For further informations please refer to user manual.



CLIPS MOUNTING TEMPLATE

